

APPLICATION PROCESS

Surface preparation is more important than applying the chemicals so prepare the surface at its best as mentioned below before starting the application.

Prepare the surface to be applied free from dust and uneven levels and make it smooth, then wash with clean water and let it dry.

- Apply 1st Coat. (Nano Coat) KABU LOCKSIL + KABU BOND + water. (1:2:20)
- Apply 2nd Coat of Fiber Mesh
- Apply 3rd, 4th & 5th coating of KABU BOND, Water & KABU G02 Powder in the ratio (1: 1: 2)
- Apply 6th Coat with KABU UV and water (1:1)
- Apply 7th Coat of KABU UV, KABU LOCKSIL & water (1: 0.1 : 1).

Drying time of each layer depends on climatic conditions.

#ArtOfWaterproofing

KABU ALL WEATHER

Replacement of Brick-bat Coba with China Mosaic on new terraces with 10 years warranty*

www.kabu.world

