## **APPLICATION PROCESS**

Surface preparation is more important then applying the chemicals so prepare the surface at its best as mentioned below before starting the application.

Prepare the surface to be applied free from dust an uneven levels and make it smooth, then wash with clean water and let it dry.

- Apply a self priming 1<sup>st</sup> Coat of KABU BOND
  : water : Cement (1:1:1)
- Apply 2<sup>nd</sup> & 3<sup>rd</sup> Coats of KABU BOND : Water
  : Cement (1 : 2 : 2)
- Apply 4<sup>th</sup> Coat of KABU BOND : Water : Cement (1 : 1 : 3)

Drying time of each layer depends on climatic conditions.

## #ArtOfWaterproofing



Waterproofing with High elastomeric compound to get upto 2 MM DFT\*

## www.kabu.world

